



## Performing the Upgrade to iRex 1.7.1 Firmware

1. Download the firmware installer to your Windows PC from [http://www.solidfx.com/downloads/FX10\\_firmware\\_1\\_71\\_1710\\_installer.exe](http://www.solidfx.com/downloads/FX10_firmware_1_71_1710_installer.exe)
2. Power on the FX10.
3. Once the Home screen is displayed, connect the FX10 to your Windows PC with the USB data cable.
4. Answer "Yes" to the question presented on the FX10 regarding whether you want to manage the device.
5. Run the downloaded firmware installer (FX10\_firmware\_1\_71\_1710\_installer.exe) and follow instructions. It should always find the FX10 automatically if properly connected and browsing to find the device should not be required.
6. The installer will automatically safely remove the FX10 connection when files have been installed. However, leave the FX10 connected while the update continues – this may take a couple of minutes during which time the unit will reboot itself multiple times.
7. Wait until the Home screen is displayed and all upgrade activity is complete before disconnecting the USB cable (i.e. the main LED light is no longer flashing).
8. Check that the firmware install was successful by selecting "Settings" on the "Home" screen followed by "About". The "Software Version" entry should read 1.7.1.

## Performing the Upgrade to FXVIEW 1.1.7

1. Download the FXVIEW installer to your Windows PC from [http://www.solidfx.com/downloads/FXVIEW\\_1\\_1\\_7\\_upgrade.exe](http://www.solidfx.com/downloads/FXVIEW_1_1_7_upgrade.exe)
2. Power on the FX10.
3. Once the Home screen is displayed, connect the FX10 to your Windows PC with the USB data cable.
4. Answer "Yes" to the question presented on the FX10 regarding whether you want to manage the device.
5. Run the downloaded installer (FXVIEW\_1\_1\_7\_upgrade.exe) and follow instructions. It should always find the FX10 automatically if properly connected and browsing to find it should not be required.
6. The installer will safely remove the FX10 connection when complete.
7. Change the default "Automatic Shutdown" time by selecting "Settings" on the "Home" screen followed by "Power Management" and then selecting 30 minutes under the heading "Choose the automatic shutdown time".
8. FXVIEW can now be started from the "Home" screen and an import of the current Jeppesen data on the device will be initiated to complete the installation – this may take a couple of minutes.

Contact [support@solidfx.com](mailto:support@solidfx.com) with any questions / issues.